



**SEAWARD**  
ELECTRICAL SAFETY TESTING  
& MEASURING.

## How do I PAT test 3 phase equipment?

If the three phase equipment has a plug, this can easily be tested with a suitable 230V-415V adaptor. Four are available, that cover 4 or 5 pin - 16A or 32A. [Click here to see a list of available adaptors.](#)

If you require more help, please contact us at <https://www.seaward.com/gb/enquiry/>.