



# How to setup the Supernova tester so it prints after test?

To be able print after the test has been completed, you will need to follow the steps below:

1. MAIN MENU
2. SETUP
3. SYSTEM CONFIGURATION
4. AFTER TEST: Select a setting containing DOWNLOAD

If you require more help, please contact us at <https://www.seaward.com/gb/enquire/>.