

How to upload a logo to a Europa?

1. Create your logo using a design application e.g Microsoft Paint.

2. Ensure the logo is set to a maximum 320 x 240 pixels.



3. Save the image as 'Monochrome Bitmap'.

	File name:	untitled.bmp	~	Save
My Network	Save as type:	Monochrome Bitmap (*.bmp;*.dib)	~	Cancel
		Monochrome Bitmap (*.bmp;*.dib) 16 Color Bitmap (*.bmp;*.dib) 256 Color Bitmap (*.bmp;*.dib) 24-bit Bitmap (*.bmp;*.dib) JPEG (*.JPG;*.JPEG;*.JPE;*.JFIF) GIF (*.GIF) TIFF (*.TIF;*.TIFF) PNG (*.PNG)		~

4. Please note that the white colour on the bitmap image will come out as black on the label. If this is not what you require, please select 'Image' from the top tool bar then 'Invert Colours'.

5. Connect your tester to the PC.

6. Open the PATGuard 2 program through the 'Start' menu and follow the links through to the 'Tester Logo Transfer' program.



7. Once opened, change 'Test N Tag Logo' to 'User Defined' using the drop down menu.

8. Next click 'Browse' and search for your logo. This will be in the file where

it was saved in step 3.

SI SNEULOGO			
E <u>x</u> it <u>A</u> bout			
Label Title			
Tester default	_		
Test 'N' Tag Logo	.	Browse	
Bitmap file:			
D:\Documents and \$	Settings\Richa	ardW\My Documen	nts\My Pictures\fluke.bmp
	СОММ ро	rt: COM5	•
		Transfer	

9. Once you have located the file, ensure that the correct Com Port is set and click 'Transfer'.

SNEULO	igo 🛛 🔀		
	Please ensure that the tester is in 'REMOTE MODE', and is connected via an RS232 cable to the correct PC comm port.		
	Click 'OK' to proceed, or 'Cancel' to abort the transfer.		
	Cancel		

10. On the tester select 'Remote Mode' from the Main Menu. Press 'Yes' (Green).

11. On the PC click 'OK'.



12. The logo is uploaded and ready to use with the Test N Tag printers.

If you require more help, please contact us at https://www.seaward.com/gb/enquire/.